



Quick guide Mini Crosser X1 Cabin



Contents

| | |
|---|-----------|
| Quick guide to the Mini Crosser X1 Cabin | 4 |
| Introduction | 4 |
| Control panel | 5 |
| Seat rotation | 8 |
| Steering column | 9 |
| Charging | 10 |
| Battery indicator | 11 |
| Serial number | 12 |
| Fuel for heater | 12 |
| Heater | 13 |
| Windscreen wiper / washer | 14 |
| Driving the Mini Crosser X1 Cabin | 15 |
| Getting in and out | 15 |
| When driving in traffic..... | 17 |
| Electromagnetic compatibility | 17 |
| Braking systems | 18 |
| Own notes | 19 |



Quick guide to the Mini Crosser X1 Cabin

Introduction

Congratulations on your new Mini Crosser X1 Cabin electric mobility scooter. You have now taken possession of an electric mobility scooter developed for outdoor driving by active users. It is what is called a Class C vehicle in according to the European standard EN 12184.

For optimum enjoyment of this vehicle - and to avoid breakdowns and accidents - we recommend that you read the User Manual carefully. As a new user, you should pay particular attention to the section entitled "Driving the Mini Crosser X1 Cabin".

Note:

This Quick Guide is to be regarded as a supplement to the User Manual. The information in the Quick Guide cannot, therefore, be expected to be complete.

NB: Errors and omissions excepted. Specifications subject to change.

We reserve the right to update this guide as required.

Warning!

The vehicle must not be lent to persons who are not completely familiar with it.

The vehicle is designed for one person only.



Max. user weight 175 kg. Can be specially adapted at the factory for users weighing up to 200 kg.

Medema A/S is not responsible for any damage or injuries caused by inappropriate or unsafe use of the Mini Crosser.



Control panel

Avoid subjecting the control panel to jarring and knocks. Take care when driving and avoid hitting obstacles.





- Air channel
- Windscreen wiper + washer
- Fresh-air/hot-air switch
- Heat regulation



- Accelerator (four-finger control)
- Accelerator (four-finger control)

The accelerator forward and backwards are physically connected, which means that when one or the other is activated, the other will move the opposite way.

| Designation | Description |
|-----------------------|---|
| Key switch | To start the vehicle: Turn the key to driving position (1) When the Mini Crosser is turned on, the control system performs a safety check of the electrical system. The check lasts half a second. If the accelerator is operated during this time, the Mini Crosser will not be able to move until you have turned the key to 0 and back to 1. |
| Speed selector | The tortoise in minimum position indicates the lowest speed range. 0-6 km/h The hare in maximum position indicates the highest speed range. Up to 15 km/h |
| Battery indicator | Lights up when the key is turned. Indicates, after half a second, the battery charge level. It gives a more precise indication after approx. 1 minute of driving. When the red, amber and green sections are lit, the batteries are fully charged. When the indicator is at the bottom of the amber section, the batteries should be charged as soon as possible. If only the red section is lit or flashing, the batteries must be charged immediately. |
| Handbrake | Acts on the rear wheel and should only be used as an extra /emergency brake and parking brake. It can be secured in locked position. Also available as a foot brake. |
| Accelerator | Activate the arm at the front slowly and the Mini Crosser will start to move forwards. The more the arm is pressed, the faster the Mini Crosser will move. When the arm is released, it will flip back to starting position of its own accord and the Mini Crosser will stop. Activating the rear arm will cause the Mini Crosser to reverse. The magnetic brake on the rear wheels will engage when the scooter is stationary and is equivalent to the parking brake on a car. The accelerator can also be used to control speed downhill. In this case the motor will act as a brake. |
| Light switch | Turns on the front and rear lights. The key switch must be in position 1 (driving position). |
| Hazard warning lights | Turns on all the indicator lights at once. Also works when the key is removed or turned to position 0 (stop position). |
| Indicator switch | Left arrow: indicator, left-hand side. Right arrow: indicator, right-hand side. Activate the same switch to turn the indicators off. |
| Horn | Powerful electric horn. Press the horn switch to activate. |
| Charging socket | Turn off the key switch during charging. Please note that it is not possible to drive the scooter while the batteries are charging. See also the section entitled "Batteries and charging". |
| Windscreen wiper | Starts the windscreen wiper. Notice the variable speed adjustment. |



| Designation | Description |
|--------------------------|---|
| windscreen washer | Spraying washer fluid on the front window. |
| Fresh-air/hot-air switch | Switch to toggle between heated and unheated air. |
| Heat regulation | Adjustable heat in the cabin. Note: Heat can be turned on even if the key is not in the key switch. Heating ribs should NOT be covered. REMEMBER! turn off the heat when you leave the vehicle. Otherwise the batteries may be flat the next time you want to use it. |

Seat rotation


It is only possible to rotate the seat in a Mini Crosser with Cabin if both doors are open.

Pull the release lever back. The seat can be rotated 90° to either side. When the lever is released, it engages with the seat and holds it in place at 45° intervals.

Other seats that can be supplied for the Mini Crosser work on similar principles. The release lever is normally mounted on the right, but can be put on the left if so wished.



Release lever for seat rotation. Release lever for seat forward/back.



IMPORTANT!

The Mini Crosser is most stable when the seat is in its lowest position. Therefore, drive carefully when the seat is up. Never use a seat lift when driving on uneven ground or in hilly landscape.

Take extra care when lowering the seat on a Mini Crosser using electric seat adjustment. Make sure that nothing is trapped in the space between the seat and the chassis.

Steering column

Can be adjusted forward/back with the release lever. Pull down on the lever and pull the handlebars closer for a good driving position. Use the lever again and push the steering column forward to make it easier to get out.

The height of the steering column can be adjusted approx. 11 cm up/down. First remove the rubber plug covering the Allen screw. Adjust the height using a 4 mm Allen key.



Adjusting the height of the handlebars.

Lever for adjusting the angle of the handlebars

Charging

The Mini Crosser should be charged while not in use. The charger supplied from the factory switches to trickle charging (very low power consumption) automatically when the batteries are fully charged. You can therefore leave the charger connected until the Mini Crosser is next used. The charger cannot overcharge the batteries.

The charger will flash until charging is complete. Then it will show a steady light.


IMPORTANT!

The charger must not be placed on the seat during charging.

IMPORTANT!

Never use charging devices other than those supplied from the factory without first contacting the dealer.

For further information see the User Manual.



NEUTRIK NC3MX charging plug



Connect the charging plug to the 3-pin socket on the steering column. The charging socket is located under the protective cover.

Battery indicator

If there is an electronic fault, a number of lamps in the battery indicator will light up. The following table shows what they mean.

For further information on troubleshooting see the User Manual.

| Lamps | Causes | Remedy |
|----------------|--|--|
| 1 lamp | The batteries need charging or the connection to a battery is poor. | Check all connections between the controller and batteries. If these are fine, try charging the batteries |
| 2 lamps | Poor connection to the motor. | Check the connection between the motor and controller. Contact supplier. |
| 3 lamps | Short-circuit between the motor and a battery connection. | Contact supplier - say how many lamps are lit. |
| 4 lamps | Not in use | |
| 5 lamps | Not in use | |
| 6 lamps | The S180 is prevented from driving. Inhibit 2 is active. This may be due to the battery charger being connected, the plug to the thermal switches being disconnected, a fault in the thermal switch or the scooter is overheating. | Stop the unit and wait 3-5 minutes before restarting. Turn the key to 0 and then to 1 to reset the fault. Contact supplier. |
| 7 lamps | Accelerator fault. | Make sure that the accelerator is in neutral when the Mini Crosser is turned on. |
| 8 lamps | Controller fault. | Contact supplier. |
| 9 lamps | Poor connection to motor brake. Magnetic brake is disengaged. | Check the connections from brake to controller, or push the brake lever up. Check that the vehicle is not disengaged. |
| 10 lamps | The controller has been supplied with a high voltage in excess of 38 V. Usually seen in the case of a poor connection. | Check all connections from the batteries to the controller. |
| Running lights | Charger is connected. | Remove charger. |



Serial number

All vehicles have a serial number plate showing the year of production, month and serial number. The same serial number can also be found on the front of the User Manual.

Please quote the serial number when making inquiries about servicing, spare parts, etc.

Fuel for heater

The tank for fuel is placed behind the seat, and filled from the outside.

Use **ONLY** paraffin or diesel.



In the front, right side of the Mini Crosser X1 Cabin, you find the the exhaustion from the heater.

NOTE! It gets **VERY** hot.

Exhaustion from heater.



Heater




Display for:
- adjusting the temperature
- remove fault code.

- turn heater on/off

Indicator light for on/off and fault code readout.

For more information: see Eberspäcker's user guide.



IMPORTANT!

The heating ribs by the window and by the legs should NOT be covered up when the heating is on. That will cause overheating of the heater.

Windscreen wiper / washer

Start the windscreen wiper by turning this knob.

Notice the smooth speed adjusting.

Windscreen wiper - turn the knob.

Washer - press this button



The Container for washer fluid is placed under the front cover.

The container for the washer fluid.



Driving the Mini Crosser X1 Cabin

Getting in and out

It is important to learn a safe technique for getting in and out of the Mini Crosser.

In general the following method should be followed:

- Make sure that the Mini Crosser X1 Cabin is off (switch turned to 0) when getting in and out, otherwise the Mini Crosser could start if the accelerator was touched inadvertently.
- Make sure that the brake is on. (Lever for disengaging motor in top position.)
- Put the steering column in vertical position.
- If necessary, raise the armrest.

Note! - Do NOT use the doors as support, when entering or getting out of the vehicle.

IMPORTANT!

The Mini Crosser will turn itself off automatically after it has been stationary for 10 minutes even if the key has been turned to driving position.

To restart the vehicle, the key must be turned to stop position (0) and then to driving position (1).



Turn the Mini Crosser off, return the steering column to upright position and raise the armrest.

General safety advice:

- Make sure that the backrest is upright and the seat is as low as possible.
- Positioning belts are recommended if the user is unable to maintain a good driving posture independently.
- Adjust your driving to road conditions. Take account of light, traffic and weather. Be particularly careful when driving in the dark or in bad weather, such as rain or snow. Avoid driving on gradients with poor surfaces, such as: snow, ice, new-mown grass, wet grass and wet leaves.
- Never drive when under the influence. This applies not only to alcohol but also to drugs and medicines.
- Reduce speed immediately if you feel you are losing control.
- Always use the indicators when changing direction.
- Check that lights and indicators are working before driving off. Use your lights when driving after lighting-up time.
- As far as possible, grip the handlebars firmly with both hands.

Take care not to have anything in the basket at the front that might inadvertently operate the accelerator.

WARNING! Do not lower the handlebars so far that the accelerator can hit you on the leg when you turn the vehicle and so be operated in inadvertently. If the handlebars need to be very low, a twist grip accelerator is recommended. This is particularly relevant if leg supports are being used.

ALWAYS switch the scooter off when it is not in use. Turn the key to 0.

Note!

Do not drive the Mini Crosser when intoxicated. This applies to both medicine and alcohol.



When driving in traffic...

Be particularly aware of the following when driving in traffic:

- The Mini Crosser is a low vehicle and not always easy for other road users to see. Make quite sure that other road users have seen you before driving onto the highway.
- Be aware of the blind spots and look around them before changing direction.
- Keep an eye on traffic behind you. Keep well over to the side of the road when driving on busy roads.
- Turning right and left at crossroads. Be aware of cyclists and pedestrians. Follow the rules of the road for cyclists.
- How quickly things are happening. How long do the lights stay green? How quickly are cars approaching? etc.

Electromagnetic compatibility

If the Mini Crosser starts making involuntary movements or if the brakes are released, turn the Mini Crosser off as soon as it is safe to do so. In certain circumstances a Mini Crosser can set off shop alarms.

The Mini Crosser satisfies the requirements for the use of scooters in an environment with electromagnetic noise. There may, however, be rare situations in which electromagnetic noise can affect the Mini Crosser. Sources of such noise include radio and television stations, amateur radio transmitters and mobile phones.

If such equipment is being used close by, it is recommended that the Mini Crosser is switched off. Mobile phones should not be used while driving.



Braking systems

There are four braking systems on the Mini Crosser:

- Motor brake - adjusts vehicle speed also when going downhill.
- Magnetic brake - the magnetic brake is automatic and engages when the Mini Crosser stops. In an emergency, the Mini Crosser can be stopped instantaneously by turning the key switch. Please note that this will cause very sharp braking. The rear wheels will lock.
Must NOT be used in the normal course of driving.
The brake must never be disengaged mechanically using the disengagement lever on a slope. This function is only designed for use when pushing the Mini Crosser on a flat road.
- Electric safety brake - if the brake is somehow disengaged on a slope/hill, the Mini Crosser will brake automatically when it reaches a certain speed. There is an electric safety feature in the control system, which works even if the battery is disconnected. This is also the reason why the Mini Crosser cannot be towed at more than 5 km/h. See the section about towing.
- Handbrake - intended as an emergency brake and parking brake. It must be operated with caution when driving in slippery conditions and downhill.



When using the hand brake as a parking brake, lock it in braking position by pressing the button in while applying the brake. To release the brake, press the button again.

Hand brake lock

Own notes





medemagroup